The best downloadable test and tag solution on the market, enabling you to test in accordance to AS/NZS 3760.



Our world beating **NEW PrimeTest Series** now comes with improved functionality and accessories, including an external rechargeable battery pack and the ability to scan and print QR codes, which makes it the ideal testing and tagging solution.

# Straightforward PAT testing with simple data management

Following in the footsteps of Seaward's long line of trusted PAT testers, the PrimeTest Series offer a comprehensive suite of electrical safety tests to enable any workplace appliance to be tested. The PrimeTest Series also enables point to point testing of fixed appliances.

In addition to the electrical tests, the **PrimeTest Elite+** offers user configurable sequences that allow users who are responsible for recording other tests or inspections to log them, and even take images that can be attached to the record.

# Visual evidence for full traceability

**PrimeTest Elite+** has a built-in digital camera enabling images taken during visual inspections and risk assessments to be tagged against records in Seaward's PATGuard 3 software as evidence - making it the most comprehensive and traceable record-keeping system.

# Why buy the new PrimeTest Series?

- > Large on-board storage
- > High definition colour display
- > Remote data transfer from field to office
- > Fixed appliance (point-to-point) testing
- User configurable tests for nonelectrical tests and inspections e.g. fire extinguishers and PPE
- > Optional additional battery for extended operating time

# PrimeTest Series Users:

- > Professional PAT Testers
- > Electrical Contractors
- > Facilities Managers
- > Operations Managers



The best downloadable test and tag solution on the market, enabling you to test in accordance to AS/NZS 3760.

# Superb software for total traceability

PrimeTest Series instruments have large internal memories capable of storing either 50,000 or 10,000 records (Elite+ and Pro respectively) and an additional 2,000 images (Elite+ only). Their compatibility with Seaward's PATGuard 3 software means that complete test records, including images, can be easily managed on a PC.

Easily transfer data to a PC remotely using the PrimeTest bluetooth function and a compatible mobile phone or tablet; or download results onto a USB flash drive (**Elite+ only**). Alternatively, transfer data directly using a USB lead when back at the office. Once downloaded to PATGuard 3, it is easy to keep track of the history of test and inspections, produce reports, certificates and invoices – offering total peace of mind and quicker, easier management of scheduling inspections and tests.

# Scan and print QR codes

Seaward's QR code data system allows more data to be stored in your PAT label barcode including; Asset ID, site, location, last and next test dates. Using Seaward's Test n Tag XL printer you can now print labels that include our unique QR data code. The **PrimeTest Elite+** has the ability to read the data contained in the code via our new Bluetooth 2D barcode scanner and populate the fields automatically for quicker retesting, without the need for data upload.

With our QR DATA Viewer app (available for both Android and iOS devices) you can share these benefits with your customers - the app allows end users to scan the labels and see the test information, they can then very easily share the data via email. This functionality allows duty holders and end users to keep better track of faulty items.

# SEAWARD SEAWARD SEAWARD SEAWARD SEAWARD SEAWARD SEAWARD

# **PrimeTest Elite+**

For complete traceability of results, including proof of visual inspection, the PrimeTest Elite+ features an on-board camera, allowing photographs to be stored alongside test and inspection data, with a comprehensive range of tests and advanced data transfer and storage features.

Designed to enable simple, professional and fast PAT testing, with remote data transfer, USB upload/download and a memory to store up to 50,000 test records and 2,000 pictures.

With point to point measurement, and fast boot-up, the PrimeTest Elite+ is the ideal companion for high-volume testing.

# **Electrical Test Functions:**

- Low current earth continuity test (with Zap circuit) guaranteeing accurate measurement
- > Insulation resistance
- > IEC lead test
- > Protective conductor current
- > Touch current
- > Load power/current
- > Alternative leakage current
- Point to point testing of earth continuity and insulation resistance
- > RCD test
- > Power socket test

# PrimeTest Elite+ Key Features:

- > On-board colour camera with flash
- Store 2,000 images
- > Store up to 50,000 appliance records
- > Ability to use (2D) QR codes
- Point to point measurement (Rpe & IR)
- > Internal RCD isolation
- > User configurable tests for nonelectical checks and inspections
- > USB for data up/download



The best downloadable test and tag solution on the market, enabling you to test in accordance to AS/NZS 3760.



# **PrimeTest Pro**

A comprehensive range of electrical safety tests ensure compliance, whilst data transfer makes data management easy and efficient.

The PrimeTest Pro is ideal for mid-volume PAT testing where detailed records are required.

Streamline the PAT testing process further by using the PrimeTest Pro with a compatible label printer, barcode scanner and PATGuard 3 software.

# PrimeTest Pro Key Features:

- > Store up to 10,000 appliance records
- > Ability to use (1D) barcodes
- > Point to point measurement (Rpe & IR) - needs optional accessory
- > Internal RCD isolation

# **Comparison Chart:**

General Features	PrimeTest Elite+	PrimeTest Pro
Compact, light and handheld	•	•
Battery & mains powered	•	•
Colour screen & QWERTY keypad	•	•
Large internal memory	Up to 50,000 records and 2,000 photos	Up to 10,000 records
Bluetooth scanner compatible	•	•
Bluetooth printer compatible	•	•
Password controlled user accounts	•	•
Set up multiple user accounts with varying levels of privileges	•	•
Clone facility to set up multiple testers	•	•
Test Inspection Features	PrimeTest Elite+	PrimeTest Pro
Auto-increment asset ID	•	•
PAT setup option to allow for custom menus	•	•
Enter asset description after test using keypad or barcode scanner	•	•
Comprehensive electrical safety test features	•	•
Point to point measurement (Rpe & IR)	•	Optional accessory required*
User configureable auto sequences	100	50
User set, sites & locations	100	50
User definable comments lines against test records	•	•
Fixed asset descriptions	•	
Large notes field	•	
Configureable checklists for any workplace test or inspection (user tests)	•	
On-board camera with flash	•	



The best downloadable test and tag solution on the market, enabling you to test in accordance to AS/NZS 3760.

# **Comparison Chart:**

Test Inspection Features (Continued)	PrimeTest Elite+	PrimeTest Pro
RCD tests	•	•
Number of asset descriptions	Up to 300	Up to 100
Polarity Pass/Fail	•	•
Earth continuity Pass/Fail/Value	•	•
Insulation Resistance Pass/Fail/Value	•	•
Class I & II Leakage Pass/Fail/Value	•	•
RCD Test Pass/Fail/Value	•	•
User Defined Tests/Routines Pass/Fail/Values	•	•
Three phase insulation	Optional accessory required*	Optional accessory required*
Three phase leakage tests	Optional accessory required*	Optional accessory required*
Data Transfer	PrimeTest Elite+	PrimeTest Pro
Wireless scanner 1D & 2D	•	•
Quick retesting facility via Seaward QR codes	•	
RFID reader connectivity (comment line only)	•	
Print Pass & Fail labels with 1D barcode	•	•
Print Pass & Fail labels with QR code (2D)	•	
Add your company logo to labels	•	•
Select from various label formats to print	•	•
Compatible with a range of wireless printers	•	•
Described and surfeed to DC site UCD cold-	•	•
Download and upload to PC via USB cable		
Data transfer via USB flash drive	•	
	•	•

<sup>\*</sup>Please contact your distributor for more details



The best downloadable test and tag solution on the market, enabling you to test in accordance to AS/NZS 3760.

# **Technical Specification:**

# Earth Continuity (Rpe)

Test Current: +/- 200mA DC

Measurement Range:  $0.05\Omega$  to  $19.99\Omega$ 

Pass Value: User defined

### **Insulation Resistance (IR)**

Test Voltage: 500V / 250VDC @ 1mA nominal Measurement Range: 0.10M $\Omega$  to 19.99M $\Omega$ 

Pass Value: User defined

### **IEC Lead Test**

Test Voltage: 5VDC nominal

Test: Live / Neutral Checks for o/c, s/c and crossed polarity

## **Protective Conductor Current/Load**

Test Voltage: Supply voltage, maximum load current 16A

Measurement Range: 0.25mA to 19.99mA

Pass Value: User defined

### **Touch Current**

Test Voltage: Supply voltage, maximum load current 16A

Measurement Range: 0.10mA to 3.50mA

Pass Value: User defined

### **Load Power/Current**

Test Voltage: 230V / 240V, maximum load current 16A Test Duration: Programmable up to a maximum of 240s

Measurement Range: 0.50A to 16.0A

### **Substitute (Alternative) Leakage Current**

Test Voltages: >25VAC <50VAC

Measurement Range: 0.20mA to 19.99mA

Pass Value: User defined

### **RCD Test**

Test Voltage: 230V / 240V

Test Current: 10mA / 30mA rms sinusoidal

Display Range: 0ms to 2000ms

Test Method: Internal isolation to avoid tripping distribution board RCD

## **Power Socket Test**

Voltage Range: 207V - 253VAC

Indicates configuration of voltage potential:-

Line potential phase to earth Line potential phase to neutral Line potential neutral to earth

### General

Memory size (PrimeTest Elite+): up to 50,000 records & 2,000 photos

Memory size (PrimeTest Pro): up to 10,000 records

Weight: 1.5kg

Dimensions: 230mm x 150mm x 100mm

Power Source: Mains or rechargeable battery pack

### What's in the box?

(Supplied as standard with PrimeTest Series)

	Elite+	Pro
PrimeTest Instrument	1	1
Professional Carry Case	1	1
Test Lead 1.2m with Alligator Clip, Red	1	1
Test Lead 1.2m with Allogator Clip, Black	1	
IEC Extension Lead, 0.5m	1	1
Black Mains Lead	1	1
USB Download Lead	1	1
UKAS Calibration Certificate	1	1
Quick Start Guide	1	1









The best downloadable test and tag solution on the market, enabling you to test in accordance to AS/NZS 3760.

# **Part Numbers:**

Instruments complete with kit PrimeTest Pro with PG3 AUS/NZ 1YR and ruck sack	380A939
PrimeTest Pro with PG3 AUS/NZ 1 YR, Test n Tag Elite 2 AUS/NZ printer and ruck sack	380A940
PrimeTest Pro Kit with PG3 AUS/NZ Outright, Test n Tag Elite 2 AUS/NZ printer, 1D scanner and ruck sack	380A941
PrimeTest Elite+ with PG3 AUS/NZ 1 YR, Test n Tag XL AUS/NZ printer, 2D scanner and ruck sack	380A942
PrimeTest Elite+ with PG3 AUS/NZ 1 YR, Test n Tag XL AUS/NZ Printer, 2D scanner and hard case	380A943
PrimeTest Elite+ with PG3 AUS/NZ Outright, Test n Tag XL AUS/NZ printer, 2D scanner and ruck sack	380A944
PrimeTest Elite+ with PG3 AUS/NZ Outright, Test n Tag XL AUS/NZ printer, 2D scanner and hard case	380A945
Instrument only PrimeTest Pro (AUS/NZ) PrimeTest Elite+ (AUS/NZ)	380A938 380A936
PATGuard 3 AUS/NZ PATGuard 3 AUS/NZ 1 Year licence PATGuard 3 AUS/NZ Outright licence	400A948 400A949
Wireless Scanners Wireless 1D scanner (AUS/NZ) Wireless 2D scanner (AUS/NZ)	339A927 339A926
Batteries and Charger PrimeTest Series external battery charger (AUS/NZ) Primetest Series spare battery (AUS/NZ)	380A021 380A9920
<b>Printers</b> Test n Tag Elite 2 AUS/NZ printer Test n Tag XL AUS/NZ printer	339A997 339A998
Leads PrimeTest Series black mains lead (AUS/NZ) PrimeTest Series USB download lead (AUS/NZ) Primetest Series red and black test lead set (AUS/NZ) PrimeTest Series red test lead (AUS/NZ)	44B165 44B189 380A951

2 year warranty (subject to terms and conditions, available at seawardprimetest.com/warranty)





